



MINI BARBECUE LIGHT

INSTRUCTIONS

- 1. Unscrew barrel from light body. Set aside the light head.
- 2. Place all 3 batteries with raised side facing downwards, as shown in figure 2.
- 3. Replace the end barrel of the light to the main light body. Be careful not to over tighten.
- Place your mini barbecue light on your tongs or spatula. Note to avoid damage it is important to place the light away from flame and direct heat.
- 5. To turn on light gently twist the end barrel of the light clockwise. Turn anti clockwise to turn off.
- 6. When storing your mini light it is recommended to store in a cool, dry place. If storing for an extended period of time, remove the batteries prior to storing.





CAUTION

- Always use the correct size and grade battery.
- Replace all batteries at the same time.
- Prior to battery installation, clean the battery contacts and device contact surfaces.
- Ensure batteries are installed correctly with regard to polarity (+ and -).
- When storing remove batteries from light body.
- Remove used batteries promptly.
- Do not place batteries in fire.
- Batteries contain mercury. Recycle or manage as Hazardous waste, do not put in trash.
- The Mini barbecue light may become hot during use, use caution when handling – BBQ glove or mitt.
- The mini barbecue light is resistant up to 79° Celsius.

- Do not leave the mini barbecue light exposed to high temperatures for prolonged periods of time.
- Do not attach the mini barbecue light to the part of the grill tool closest to the cooking grid.
- Do not put the mini barbecue light directly into flame or flare ups. As this could damage the mini light and/or cause the batteries to explode or leak.
- Do not submerge in water. To clean wipe the outer surface with a damp cloth then dry with a clean dry cloth.
- Do not store batteries or battery-powered devices in high temperature locations. This may cause damage to the product and batteries.
- To prevent scratching on barbecue tools, do not slide the mini light up and down the tool handle.

BATTERY REPLACEMENT

Use AG13/LR44 1.5 volt button cell alkaline batteries.